GAUGE SETS ASSEMBLY INSTRUCTIONS

STEP 1: Locate flange with "T" for TOP (this side has a deeper well).

- **STEP 2:** Assemble glass into "T" side with nut and neoprene seal in place on glass for both ends.
- STEP 3: Push glass up into deep well, swing glass over insert in flange marked "B", then slide into flange "B" well.
- **STEP 4:** Slide nut and seal along the glass and screw into position on flanges.

STEP 5: Check for leaks.

GAUGE SETS ORDERING INFORMATION

When you order a gauge set, you will receive 2 gauge valves, 1 piece of glass, and 4 rods. For example, a 301 gauge set would include the 2 gauges, 1 piece of 12" glass, and 4 rods. The set can be purchase without the glass and rods (-WO), or with any length of glass you require.

To custom order a glass length other than the standard 12" length, order the gauge set you need without glass (e.g., 301 (-WO)) and then specify the glass length and rods you want (SEE NOTE BELOW).

Custom glass and rod prices vary: contact us for a quote. Red line glass is also available.

NOTE: To figure length of glass required, subtract 2 3/8" from the distance of the centers. Order rods lengths 3" longer than the glass required.